

# Basic Instructions

## 1. Synchronize Controller and Motor

Press (SET) and (O) buttons together for 3 seconds, the indicate lights will flash, then press and hold the code button on the motor until it flashes blue.

## 2. Automatic Lens Calibration

Press (SET) and (A) buttons together for 3 seconds, it will automatically find the start and end points of the lens swivels.

## 3. Manual Lens Remapping

Press (SET) and (REC) buttons together for 3 seconds, (A) (B) (C) (D) will light up. Press (C) to rotate the lens clockwise, then press (A) to choose the start point. Press (D) to rotate counter clockwise and press (B) to choose the end point.

## 4. Set up Presets

Go to the focus point of your choosing. Press and hold (A) until it flashes. You're point is now set. Repeat with (B) (C) and (D) for multiple points.

## 5. Change Motor Spin Direction

Press the code button on the side of the motor to reverse the direction of gear.

## 6. Remote Recording Trigger

Press (REC) , Record ON/OFF, Support ARRI, RED, Sony, Canon professional camcorder.

