


## OTHER ACCESSORIES



Shown w  
Optional Skirt Kit  
#1832



Chimera/Matthews  
Grip Head  
#3750



Chimera  
Panel Camp  
#3760



Single Axis Stand  
Adapter  
#3860



Dual Axis Stand  
Adapter  
#3865


### Warranty Information

For the LiteGear components: LiteGear™, Inc., ("LiteGear™") warrants your Light Engines & Dimmers to be free from physical defects in material and workmanship for a period of one (1) year from the date of the original retail purchase; some exceptions apply (see full warranty statement on line). If you discover a defect covered by this warranty, LiteGear™ will repair or replace the product at its sole discretion using new or refurbished components.

For the Chimera components: Chimera's Fabric Light Control Accessories come with a limited 5-year warranty against manufacturing defects in materials, workmanship, and color stability. If our products are not fully operational out of the box or if they fail to perform within five years from the date of purchase, you can return it for repair or replacement at no charge. Chimera's warranty does not cover damage caused by accidents, improper care or use, or the natural deterioration of materials over an extended period of time.

**A RETURN AUTHORIZATION (RA) MUST BE OBTAINED FROM THE  
FACTORY PRIOR TO ANY RETURN!**

p/n: 18509700



**CHIMERA**  
PERFECT LIGHTING

## Panel Lantern

Powered by LifeGear  
1850 / 1835


Instructions for Assembly, Care and Use



## Assembly

### 1. Construct the Panel Frame

Insert the metal tubes into the ferrules on each of the 4 corners, going around the frame until all corners are secured. For more guidance refer to the Panel Frame Instructions that are included in the Panel Frame sack.



### 2. Unfold and Attach Head Unit

Attach the Head Unit to the 2'x2' Panel Frame using the elastic straps on all 4 corners. Ensure that the straps are situated over the rear of the Head Unit, so not to obstruct the output of the LEDs.



### 3. Connect Head Unit to the Dimmer

If needed, use the 12'(3m) extension cable. Next, connect the opposite end of the cable to the LieiGear LieiDimmer. Line up the white arrow and the connectors should simply push together, and you should hear a click when they are connected.



### 4. Connect the Dimmer to the Power Supply

Connect the M barrel connector on the power supply to the F barrel connector on the LieiDimmer. For operation of the LieiDimmer, please refer to the instructions included with the dimmer.



### 5. Connect the Power Supply to Line Power

Note that models shipped outside of North America include an international color-coded leader cable and the installation of a plug compatible with the local jurisdiction is required.

### 6. Attach the Chimera Lantern

#### Fabric

Attach the fabric to the Frame by stretching the elastic straps on the four corners over the four corners of the Panel Frame. Ensure that the straps sit on the rear of the Head Unit, to avoid them blocking any light from the LEDs.



Your Chimera Panel Lantern Powered by LieiGear is now fully assembled! The Panel Clamp (3760), or the specially-designed Matthews 2 1/2" grip head (3750) can be used to rig the Panel Lantern in numerous ways.

#### Disassembly and Storage

Disassemble and re-pack the Panel Lantern in reverse order of assembly.

Fold the Head Units in half and replace carefully into the padded section of the storage bag.

### TAKE CARE NOT TO ROLL THE HEAD UNIT THAT CONTAINS THE LED LIGHT ENGINES.

Store in a cool, dry place, free from dust or static discharge.

#### Cleaning

The lantern fabric can be cleaned by hand washing with cold water, a sponge and mild soap. Do not machine wash. To dry, hang and completely allow to air dry.